

### OCEANDRY Freedom stock size chart

SIZE	WEIGHT	HEIGHT	CRUTCH TO FLOOR	CHEST	WAIST	UNDER ARM TO WRIST
Medium/Short	57-67	164-174	74-78	102-107	89-94	54
Medium	64-70	168-178	78-82	102-107	89-94	54
Medium/Tall	64-73	174-184	84-88	102-107	89-94	60
Large/Short	86-92	167-177	74-78	107-112	93-98	56
Large	86-92	174-184	81-85	107-112	93-98	56
Large/Tall	92-98	180-190	87-91	107-112	93-98	62
XL/Short	98-105	172-182	74-78	117-122	104-109	57
Extra/Large	98-105	179-189	81-85	117-122	104-109	57
XL/Tall	101-108	188-198	89-93	117-122	104-109	62
XXL/Short	101-108	174-184	74-78	121-126	109-115	58
XXL	108-120	183-193	83-87	121-126	109-115	58
XXL/Tall	111-124	189-199	89-93	121-126	109-115	63
Boot Size	NZ	UK	Advise us for correct boot size fitted			